

## HTC VIVE BUSINESS+ PRO



Cena celkem:	<b>4 890 Kč</b> <b>(bez DPH: 4 041 Kč)</b>
Běžná cena:	<b>5 379 Kč</b>
Ušetříte:	<b>489 Kč</b>
Kód zboží:	VRHTC0028
Part No.:	69HVABMSB36M01-00
Záruka:	12 měs. IČO / 24 měs. EU
Stav:	Nové zboží

## Popis

### HTC Business+ Pro

**HTC VIVE Business+** je řešení softwaru a služeb pro správu **HTC VIVE Focus 3**. Přizpůsobte si samostatné náhlavní soupravy VR tak, aby vyhovovaly vašim firemním potřebám. Licence je platná 3 roky. Verze Pro nabízí **1 GB cloudového úložiště** pro sdílení map.

Licence je určena **pro komerční použití**. VIVE Business+ nepodporuje licencovaný obsah z VIVE Business AppStore nebo VIVEPORT.

#### Správa zařízení

Rychle a snadno zaregistrujte náhlavní soupravy pomocí naskenování QR kódu, aktualizujte nastavení/konfigurace hardwaru a spravujte svá zařízení na dálku.

#### Správa obsahu

Nahrávejte vlastní obsah, spravujte knihovnu a instalujte aplikace do všech náhlavních souprav VIVE Focus 3 odkudkoli.

#### Vzdálená správa obsahu

Přístup k obsahu a jeho správa v rámci organizace není nikdy jednoduchá. VIVE Business+ umožňuje vzdáleně nahrávat a spravovat všechny aplikace a verze v cloudu. Centrálně spravujte a spolehlivě škálujte svá nasazení.

#### Správa uživatelů

Přidejte uživatele a nastavte oprávnění pro role správce, editora či diváka. Vytvořte více organizací pro samostatné týmy. Udržujte kontrolu nad všemi na jednom místě.

#### Správa skupin

Vytvořte skupinu pro svá zařízení a rychle a efektivně nasazujte aktualizace nebo aplikujte přizpůsobitelná nastavení. Změňte skupinová nastavení ROM, aplikací, map a zobrazte okamžité aktualizace ve všech seskupených zařízeních.

## Pokročilé funkce

Poskytněte uživatelům lepší zážitky díky přizpůsobitelným možnostem uživatelského rozhraní a režimům sledování VIVE Location-Based Software Suite (LBSS).

## Vzdálené monitorování a ovládání zařízení

Sledujte stav baterie náhlavní soupravy a ovladače, stav Wi-Fi a další důležité údaje. Mějte lepší kontrolu nad svými zařízeními odkudkoli. Vzdáleně restartujte, vypínejte a resetujte náhlavní soupravy do továrního nastavení.

## Funkce a vlastnosti:

VIVE BUSINESS+ FEATURES						
	FEATURES	DESCRIPTION	STANDARD	PRO	ULTIMATE	NOTES
User Admin	Overview Dashboard	Organization enrolled device lists, available seats, expiration... etc.	•	•	•	
	Role-based User Management	Admin, Editors, Viewer roles	•	•	•	
	Member Management	Add, delete, and assign user accounts to organizations	•	•	•	
	Permission Management	Admin privileges for modifying user permissions	•	•	•	
	Cloud Storage	Storage for configurations, maps, and custom content files for remote installation		1GB	5GB	per device
	Code Redemption	Organization creation and seats redemption	•	•	•	
Device Management	NEW QR Code Enrollment	QR-Code initiated device setup and enrollment for the VIVE Focus 3	•	•	•	
	NEW Standard Device Status	Device battery level, sync time... etc. dashboard	•	•	•	
	NEW Batch Configuration	Batch configuration for device groups	•	•	•	
	NEW Device Groups	Device grouping and group management features	•	•	•	
	NEW Issue Report/Tracking	Device logging on VBMS and issue ticketing	•	•	•	
	NEW Remote Device Management	Remote device reboot, shutdown, and wipe... etc.	•	•	•	
	NEW Advanced Device Status	Device storage, content list... etc.		•	•	
	NEW Remote Content Management & Distribution	Remote content installation and distribution to device groups over network (APK and OBB files)			•	
	Customized Boot Screen	Custom device boot up animation			•	
System Updates	Offline Device ROM Update	Update to ROM manually using SD card	•	•	•	
	NEW Device management and FOTA Assignment	System version management, supporting device groups and support force updates.	•	•	•	
	NEW ROM Update via SD Card	Automatically update to specific ROM version directly by SD card			•	
Advanced Tracking Features (LBSS)	Visual Odometry (VO) Tracking Mode	Access to VO Mode	NEW •	•	•	
	Immersive Customization	Disable default system UI elements (refer to batch configuration)		•	•	
	LBE Configurations	Tracking mode selection and corresponding settings (refer to batch configuration)		•	•	
	Map Sharing	Map sharing between HMDs for alignment		•	•	
	Advanced Tracking Features	MBLS, MBSA, Drift Prevention Mode		•	•	

BATCH CONFIGURATION SETTINGS						
	FEATURES	STANDARD	PRO	ULTIMATE		
General	System language	•	•	•		
	Timezone	•	•	•		
	Network Time enabling	•	•	•		
	Double click to show pass through	•	•	•		
	Allow BT	•	•	•		
	Hand tracking enable/disable	•	•	•		
	Show/hide Vive Sync	•	•	•		
Wi-Fi settings	Wi-Fi certificate	•	•	•		
	Wi-Fi setup	•	•	•		
	VPN certificate	•	•	•		
	VPN setup	•	•	•		
Device settings	Boundary color	•	•	•		
	Boundary transparent	•	•	•		
	Show pass through automatically when out of boundary	•	•	•		
	Always show floor bound	•	•	•		
	Power frequency	•	•	•		
	Allow recording and casting	•	•	•		
	USB debugging	•	•	•		
Kiosk mode	Period to enter sleep mode	•	•	•		
	Hide pre-loaded content -> VIVE Sync	•	•	•		
	Hide pre-loaded content -> Firefox Reality	•	•	•		
	Hide pre-loaded content -> VIVE Business Streaming	•	•	•		
	Kiosk mod - select content	•	•	•		
	Kiosk mod - password	•	•	•		
	Kiosk mod - Activate kiosk mode	•	•	•		
	Kiosk mod - network mode (any, pre-set, offline)	•	•	•		
	Kiosk mod - interaction mode	•	•	•		
	Kiosk mod - Show/hide tutorial/opening video/wearing guide	•	•	•		
Kiosk mod - Allow BT connection	•	•	•			
UI Related	Disable controller pairing and the UI after initial setup			•	•	
	Disable Vive menu on the R controller and HMD button			•	•	
	Disable Function Menu			•	•	
	Disable USB connection dialog			•	•	
	Disable Volume adjustment Bar			•	•	
	to consent volume warning dialog by volume up key			•	•	
	Disable Volume safety notification			•	•	
	Disable low battery notification			•	•	
	Disable IPD adjustment overlay			•	•	
	Skip OOB			•	•	
Customization	Customized boot logo			•	•	
	Customized boot animation			•	•	
	Customized boot duration (logo & animation)			•	•	
	To Hide tabs from MainNav			•	•	
	enable System firmware update management			•	•	
Tracking Features	Disable content transition			•	•	
	Disable shutdown screen image			•	•	
	enable Lost tracking event integration			•	•	
	Disable lost tracking animation			•	•	
	Disable lost tracking black background			•	•	
	Marker-based location sharing (VO mode only)			•	•	
	enable Marker-based drift prevention			•	•	
	Disable Reset View function			•	•	
	Support 1 controller 1 wrist tracker			•	•	
	Enable hand tracking as default			•	•	
HW Keys	Disable VIVE button on right controller			•	•	
	Disable volume up/down buttons on HMD			•	•	
	Disable Headset button on HMD			•	•	
	Disable hand gesture "palm pinch"			•	•	
	Pop up Vive menu by single click headset button			•	•	
enable 2 ways communication on wrist tracker			•	•		

# BUSINESS BUILDING BLOCKS

## BUSINESS WARRANTY AND SERVICES

### Business Warranty & Support 2 or 3 years

Enterprise-grade support and services to protect your investment.

Two (or 3-years ) warranty, phone support and expedited repair



### VIVE Advanced Device Management System –services

#### Standard Tier Included with BWS

New VIVE Advanced Device Management System features

- QR Code enrolment
- NEW Device Status
- NEW Group Management
- XR Elite 3<sup>rd</sup> Party MDM use



#### Pro Tier Optional (F3 only)

- Remote Device Management
- Advanced device status
- Focus 3 Location Based Software Suite



#### Ultimate Tier Coming Later (F3 only)

- Content management and delivery with more content storage
- Advanced features like deep API integration

